

WARNING

OFF

OK

WARNING

OFF

MOUNTING INCLINE

1

2

END FEED'S ELECTROMECHANICAL CONNECTIONS

95 31.4

0.02038.00
Left End-feed

0.02039.00
Right End-feed

INCLINE DRIVER INCLINE DRIVER

MOUNTING DRIVER

1

2

DALI

ON

2-1-3

ON

MOUNTING CLUSTER

1

2

Max 3,0 Kg.

MOUNTING SPACER

1

MOUNTING CLUSTER (WITH LONG/FLEXIBLE SPACER)

300 / 400 / 600 / 800 / 1000 / 1200 mm

1

MOUNTING PROJECTOR (VERTICAL)

Max 3,0 Kg.

1

DISASSEMBLY DRIVER

OFF

1

OFF

2

3





4

DISASSEMBLY INCLINE


1

2


MOUNTING INCLINE




MOUNTING CLUSTER




USING THE ADAPTER




WARNINGS




USING THE ADAPTER




WARNINGS



USING THE ADAPTER



WARNINGS



WARNINGS

